

STL1A Instructions

This is a demonstration on how to use the STL1A. It is mounted in a comfortable position where your arm can easily reach. Maybe somewhere near your shifter. It is mounted with 2 #10 button head screws 1.5 inches apart. Before you pull into the staging beams reach your finger to the front of the trigger and cock it by pressing on the #10 carriage bolt head. Once you are staged push the pistol grip handle ahead to set the trans brake. While holding this forward you are ready to fire or launch your car by pulling the trigger. The knob at the bottom of the trigger helps you locate your finger in the same position each time. Once you have released the car you cannot lock the trans brake until you cock it and push in the handle. Pulling the trigger when car is moving will do nothing until you've cocked the trigger and pushed in the handle. That's all there is to it. Just cock it, push in, and pull to fire.