

STL2B Instructions

This is a demonstration on how to use the STL2B. It is mounted in a comfortable position on the butterfly steering wheel cover plate, that comes with the STL2, with two #6 button head screws 1.5 inches apart where you can easily reach to operate. You can also mount it to your own plate or trim the plate supplied to fit different butterfly wheels. As you pull into the staging beams place your middle finger on the lever furthest away and pull towards you once you've lit the second staging beam. You are staged. Now place one or two fingers using the fingerprint portion of your finger or pads on the trigger closest to you and pull to launch. The knob at the bottom of the trigger helps you locate your finger in the same position each time. Once you have released the car you cannot lock the trans brake until you pull to cock the furthest lever. Pulling the trigger when car is moving will do nothing until narrow lever has been cocked. That's all there is to it. Just pull to cock and pull to fire.