

## **STL1B Instructions**

This is a demonstration on how to use the STL1B. It is mounted in a comfortable position where your arm can easily reach. Maybe somewhere near your shifter. It is mounted with 2 #10 button head screws 1.5 inches apart. As you pull into the staging beams place your middle finger on the lever furthest away and pull towards you once you've lit the second staging beam. You are staged. Now place one or two fingers using the finger print portion or pads of your finger on the trigger closest to you and pull to launch. The knob at the bottom of the trigger helps you locate your finger in the same position each time. Once you have released the car you cannot lock the trans brake until you pull to cock the furthest lever. Pulling the trigger when car is moving will do nothing until the lever is pulled to cock the trigger. That's all there is to it. Just cock and pull to fire.