

STL3 Instructions

This is a demonstration on how to use the STL3. It is mounted in a comfortable position on the steering wheel with two #6 button head screws 1.5 inches apart where you can easily reach to operate. You can also mount it to a small plate bolted to your wheel if needed to accommodate a better position. As you pull into the staging beams place your middle finger on the narrow lever furthest away and pull towards you once you've lit the second staging beam. You are staged. Now place one or two fingers on the wide lever and pull to launch. Once you have released the car you cannot lock the trans brake until you pull to cock the narrow lever. Pulling the wide lever when car is moving will do nothing until narrow lever has been cocked. That's all there is to it. Just pull to cock and pull to fire.